

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
TWINGO	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
TWINGO phase 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
MODUS	Injection	√	√	√	√	√			
	a.b.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	variable p.a.s	√	√	√	√		√		
	instrument panel	√	√	√	√	√	√		
	airbag/pretensioners	√	√	√	√		√		
	UPC	√	√	√	√		√		
	UCH	√	√	√	√	√	√		
CLIO	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	automatic gearbox	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	engine immobiliser	√	√	√	√	√			√
	airbag/pretensioners	√	√	√	√	√			
CLIO 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√	√		
	airbag/pretensioners	√	√	√	√	√			
CLIO II PH 2/3/4	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√		√	
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√	√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
discharge lamp	√	√	√	√	√				
CLIO III	Injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	variable p.a.s	√	√	√	√		√		
	instrument panel	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	airbag/pretensioners	√	√	√	√		√	√	
	UPC	√	√	√	√	√			
	UCH	√	√	√	√	√			
	LIGHTING	√	√	√	√	√	√	√	
THALIA/SYMBL	petrol injection	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
CLIO V6	petrol injection	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			
CLIO V6 PH 2	petrol injection	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			√
	interconnection unit	√	√	√	√	√			
	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
MEGANE/SCENIC	engine immobiliser	√	√	√	√	√		√	√
	diesel injection	√	√	√	√		√	√	√
	interconnection unit	√	√	√	√	√		√	
	airbag/pretensioners	√	√	√	√		√		√
	hood control	√	√	√	√	√			
	tyres	√	√	√	√	√	√	√	
MEGANE II	Injection	√	√	√	√	√			
	air conditioning	√	√	√	√		√	√	
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√				
	instrument panel	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√	√	
	uch	√	√	√	√	√			
	upc	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√	√		
	lighting	√	√	√	√	√	√		
	sunroof	√	√	√	√	√	√	√	
SCENIC II	Injection	√	√	√	√	√	√		
	air conditioning	√	√	√	√		√	√	
	a.b.s	√	√	√	√	√			
	variable p.a.s	√	√	√	√				
	instrument panel	√	√	√	√		√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
	upc	√	√	√	√	√	√		
	parking brake	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	parking assis	√	√		√	√	√	√	
	uch	√	√	√	√	√	√	√	
LAUGNA	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√	√			√
LAGUNA phae 2	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√		√	
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
LAGUNA II	injection	√	√	√	√	√	√		√
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√		√	
	instrument panel	√	√	√	√	√		√	
	automatic gearbox	√	√	√	√	√		√	

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
LAGUNA II	UCH	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√		√
	discharge lamp	√	√	√	√	√	√	√	
	parking assistance	√	√	√	√				
	heater	√	√	√	√	√			
LAGUNA II PH2	injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√	√	√	
	air conditioning	√	√	√	√	√	√	√	
	instrument panel	√	√	√	√	√	√	√	
	automatic gearbox	√	√	√	√	√		√	
	uch	√	√	√	√	√	√	√	
	airbag/pretensioners	√	√	√	√	√	√	√	
	parking brake	√	√	√	√	√	√	√	
	lighting	√	√	√	√	√	√		
	parking assistance	√	√	√	√				
SAFRANE	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	door management	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
VEL SATIS	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√			
	air conditioning	√	√	√	√	√			
	variable p.a.s	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				
	door management	√	√	√	√	√			
	discharge lamp	√	√	√	√	√			
	tyres	√	√	√	√	√			
	heat	√	√	√	√	√			
	parking assistance	√	√	√	√				
	parking brake	√	√	√	√	√			
AVANTIME	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	instrument panel	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√				

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions								
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command	
	heat	√	√	√	√	√				
	discharge lamp	√	√	√	√	√				
ESPACE	petrol injection	√	√	√	√	√	√			
	a.b.s	√	√	√	√					
	air conditioning	√	√	√	√	√				
	instrument panel	√	√	√	√	√				
	automatic gearbox	√	√	√	√	√				
	engine immobiliser	√	√	√	√	√				
	diesel injection	√	√	√	√	√	√	√		
	interconnection unit	√	√	√	√	√				
	airbag/pretensioners	√	√	√	√					
	door management	√	√	√	√	√				
	heat	√	√	√	√	√				
	discharge lamp	√	√	√	√	√				
	ESPACE IV	petrol injection	√	√	√	√	√	√		
		a.b.s	√	√	√	√	√	√	√	
air conditioning		√	√	√	√	√	√	√		
variable p.a.s		√	√	√	√	√	√			
instrument panel		√	√	√	√	√	√	√		
automatic gearbox		√	√	√	√	√				
engine immobiliser		√	√	√	√	√	√	√		
diesel injection		√	√	√	√	√			√	
interconnection unit		√	√	√	√	√				
airbag/pretensioners		√	√	√	√		√	√		
door management		√	√	√	√	√				

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
	discharge lamp	√	√	√	√	√			
	tyres	√	√	√	√	√			
	parking assistance	√	√	√	√				
	heat	√	√	√	√	√			
	lighting	√	√	√	√	√	√	√	
	hands free kit	√	√	√	√	√	√	√	
	parking brake	√	√	√	√	√	√	√	
ESPACE VI PH2	PANEL	√	√	√	√	√	√	√	
	UCH	√	√	√	√	√	√	√	
KANGOO	petrol injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	air conditioning	√	√	√	√	√			
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√			
	heat	√	√	√	√	√			
airbag/pretensioners	√	√	√	√		√		√	
KANGOO MUX	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	automatic gearbox	√	√	√	√	√			
	engine immobiliser	√	√	√	√	√			
	diesel injection	√	√	√	√	√	√	√	√
	interconnection unit	√	√	√	√	√			
	airbag/pretensioners	√	√	√	√		√		√

Renault V38.00 Diagnostics List (Note: For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
TRAFIC	airbag/pretensioners	√	√	√	√				
	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	engine immobiliser	√	√	√	√	√			
TRAFIC II	airbag/pretensioners	√	√	√	√		√	√	
	petrol injection	√	√	√	√	√	√		
	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√				
	engine immobiliser	√	√	√	√	√			
	interconnection unit	√	√	√	√	√	√		
	heat	√	√	√	√	√			
TRAFIC II PH2	injection	√	√	√	√	√	√	√	
	airbag/pretensioners	√	√	√	√		√	√	
	uch	√	√	√	√	√	√	√	
MASTER	airbag/pretensioners	√	√	√	√				
	diesel injection	√	√	√	√	√	√	√	
	petrol injection	√	√	√	√	√	√		
	a.b.s	√	√	√	√				
	interconnection unit	√	√	√	√	√		√	
	engine immobiliser	√	√	√	√	√		√	
MASTER PH 2	diesel injection	√	√	√	√	√	√	√	
	a.b.s	√	√	√	√	√		√	
	interconnection unit	√	√	√	√	√	√	√	
	engine immobiliser	√	√	√	√	√			

Renault V38.00 Diagnostics List (Note:For reference only)

Vehicle	Systems	Functions							
		System Info	Read Dtc	Clear Dtc	Data stream	Actuation	Read configuration	Configuration	Command
R25	petrol injection	√	√	√	√	√	√		
ALPINE	petrol injection	√	√	√	√	√	√		

(*):Tested;

(?):Manual on website(www.x431.com)

Note:All description rights reserved by LAUNCH TECH.CO.,LTD

CONNECTOR	X431	DIAGUN
OBD 16C	Follow the connector indication in the software	N/A
CANBUS II	Follow the connector indication in the software	N/A
DIAGUN CONNECTOR	N/A	All 16pin DLC
SUPER 16	All 16pin DLC	N/A